

Premium Saddlebag Lid Covers - Installation Instructions

*The lid covers can be easily installed while the lids are still attached to the saddlebags. No tools are required!!
These covers are designed to have a tight, snug fit. The tighter you put them on, the better their appearance will be.*

DO NOT USE A HEAT GUN AT ANY TIME ON THIS PRODUCT!! They can be relaxed if left in the sun for a few minutes.

- 1 - Clean underside of lid of any dust or debris. Then use the provided alcohol prep pads to wipe the lids clean. Allow to dry completely.
- 2 - Place provided Velcro strips just below the lids weather-stripping.
- 3 - Loosely wrap the fleece-lined cover around the lid.
- 4 - First secure the rear, and then secure the front of the cover to the Velcro.
- 5 - Then proceed to secure the inside and outside.

There may be some adjustments needed to achieve proper fit. When complete, there should be no looseness or wrinkles visible.

FOR BEST RESULTS:

- WARM the lid covers in a warm sun for about 5 minutes,
- PUSH the cover in place with your bottom hand,
- PULL the Velcro tabs with your top hand, and then
- ROLL the seam in place over the lids edge with the fingers on your bottom hand

***Special Note for 2014 to Present Models:** The lid closure tolerance is tighter than previous years.

- 1 - Make sure the covers are fully installed with the provided Velcro.
 - 2 - Use the palm of your rear hand to push down on the back of the lid, while using your front hand to push the front latch down.
- Using this approach will help the lids close much easier. This will only be necessary for a short period while your covers break-in.



WWW.SHOREFIREDESIGN.COM

Individually Handcrafted with
Pride in the USA



Any Questions?

Please Call
1-844-4-SF LIDS
(1-844-473-5437)